


1


REMOVE FRONT FOOTPAD

- REMOVE THE TWO FLATHEAD CAP SCREWS ON THE FOOTPAD CLOSE TO THE WHEEL WITH THE PROVIDED STAR KEY.



- FLIP BOARD OVER AND REMOVE THE SIX FLATHEAD CAP SCREWS ON THE UNDERSIDE OF THE FRONT BUMPER.


NOTE: THE HARDWARE IS HELD IN PLACE USING A THREAD LOCKING COMPOUND AND MAY REQUIRE SOME FORCE TO REMOVE. FLIP BOARD RIGHT-SIDE UP FOR NEXT STEP.



2


LIFT FOOTPAD AND REMOVE BUMPER

- LIFT THE FOOTPAD FROM THE FRONT AND REST IT ON THE WHEEL TO REDUCE STRESS ON CABLES.



- REMOVE OLD FRONT BUMPER BY PULLING AWAY FROM THE BOARD.

NOTE: REMOVAL MIGHT REQUIRE SOME FORCE DUE TO SNUG FIT.





3

BUMPER INSTALLATION

- INSTALL NEW FRONT BUMPER BY CAREFULLY LINING UP THE TABS AND SLOWLY PRESSING DIRECTLY TOWARDS THE BOARD.


NOTE: INSTALLATION MIGHT REQUIRE SOME FORCE DUE TO SNUG FIT.



4


INSTALL FRONT FOOTPAD

- PLACE THE FRONT FOOTPAD DOWN LINING UP THE TWO HOLES. USE THE TWO SHORTER SCREWS TO ATTACH THE FOOTPAD.



- FLIP BOARD OVER AGAIN AND REPLACE THE SIX FLATHEAD CAP SCREWS ON THE UNDERSIDE OF THE FRONT BUMPER.

NOTE: IT IS RECOMMENDED TO START ALL SCREWS BEFORE SNUGGLY TIGHTENING THEM DOWN. THIS HOLDS TRUE FOR ANY REASSEMBLY YOU ARE GOING TO BE PERFORMING ON YOUR ONEWHEEL PINT.





FOR INSTRUCTIONAL VIDEOS & TIPS
VISIT [ONEWHEEL.COM/PAGES/SUPPORT](https://www.onewheel.com/pages/support)


[ONEWHEEL.COM](https://www.onewheel.com)

5

REMOVE BACK BUMPER


- REMOVE THE FOUR FLATHEAD CAP SCREWS ON THE UNDERSIDE OF THE BACK BUMPER.

NOTE: THE HARDWARE IS HELD IN PLACE USING A THREAD LOCKING COMPOUND AND MAY REQUIRE SOME FORCE TO REMOVE.



- REMOVE OLD BACK BUMPER BY PULLING AWAY FROM THE BOARD.


NOTE: REMOVAL MIGHT REQUIRE SOME FORCE DUE TO SNUG FIT.



6


INSTALL BACK BUMPER

- INSTALL NEW BUMPER BY CAREFULLY LINING UP THE TABS AND SLOWLY PRESSING DIRECTLY TOWARD THE BOARD.



- REPLACE THE FOUR FLATHEAD CAP SCREWS ON THE UNDERSIDE OF THE BACK BUMPER.

NOTE: IT IS RECOMMENDED TO START ALL SCREWS BEFORE SNUGGLY TIGHTENING THEM DOWN. THIS HOLDS TRUE FOR ANY REASSEMBLY YOU ARE GOING TO BE PERFORMING ON YOUR PINT.



DIY USER'S
MANUAL

pint